




# 2300 Series

**Model : 2300**



# Amendment Record

## 2300 Series

Models: 15744,15849,22258,21877,21879,22260

50202 / SJ 4773

Manufactured by Fairbanks Scales Inc.

821 Locust

Kansas City, Missouri 64106

Created 12/98

Issue #1 12/98 New Product Release

Issue #2 7/99 Software Update, added 5 digit part numbers, added 610 printer

Issue #3 02/01 Added battery operated models

Issue #4 6/01 Update the Troubleshooting page and Technical Specifications ( NEMA 4)

# Table of Contents

## **Section 1: Introduction**

A. Description.....	5
B. Model Differences.....	5
C. Intended Application(s).....	6

## **Section 2: Technical Specifications**

A. Weights & Measures Approvals.....	7
B. Models & Capacities.....	7
C. Environment Considerations.....	7
D. Power/ Grounding Needs.....	7
E. Instrument Capabilities.....	7
1. Number of Cells.....	7
2. Div size.....	7
3. Counts/div.....	7
4. Cable lengths.....	7
5. Excitation Voltage.....	7
6. Battery Life.....	7

## **Section 3: Setup**

A. Unpacking.....	8
B. Installing .....	8
C. Power-Up Sequence.....	9

## **Section 4: Programming**

A. Keyboard Layout .....	10
B. Getting Started with Menus and Programming.....	11
C. Info Menu .....	12
1. Setting Time and Date.....	13
D. BAtt Menu .....	14

## **Section 5: Operation**

A. Keyboard Features.....	16
B. Other Key Functions.....	16
C. Weighing Operation.....	17

## Section 6: Troubleshooting

A. Troubleshooting Error Code Chart.....	18
--	----

### Appendix:

Appendix I: PTR-3950 Ticket Printer.....	19
Appendix II: PTR-3960 Ticket Printer.....	20
Appendix III: 50-3921 Form Printer.....	21
Appendix IV: 610 Ticket Printer.....	22
Appendix V: 3550 Tape Printer.....	23
Appendix VI: 3715 Tape Printer.....	24
Appendix VII: Interface Cables/Pin-Outs.....	25
Appendix VIII: Port 1 Data Stream.....	26
Appendix IX: 4-20mA Options.....	28
Appendix X: ASCII Chart .....	30

### Disclaimer

Every effort has been made to provide complete and accurate information in this manual. However, although this manual may include a specifically identified warranty notice for the product, Fairbanks Scales makes no representations or warranties with respect to the contents of this manual, and reserves the right to make changes to this manual without notice when and as improvements are made.

# Section 1: Introduction/Description



**Caution: This product is shipped from the factory set for 110-120 VAC operation. For 220-240 VAC operation, settings must be changed before powering up. See power settings below for 220-240 VAC.**

**Power Settings:**

**AC Power can be set for 110/120VAC OR 220/240VAC via jumpers @ JP1 on Power PCB# 15759 or 21514, confirm setting.**

**For 220/240VAC = Jumper only center positions "B"**

**For 110/120VAC = Jumper both end positions "A" and "C"**

**A. Description:**

The 2300 Series instrument is an all purpose analog weight indicator with the following features:

- 6 digit, 7 segment .56" LED display
- Full numeric keypad
- LED indicators for modes and functions
- Outputs, and two (2) inputs for external switches
- Choice of AC only or Battery & AC power (when ordering only)

**B. Model Differences:**

- Original model units did NOT have an ON/OFF switch on the keypad and are AC only.
- Neither their software nor their hardware allow battery operation or battery add-on.
- Parts from an original may NOT be used in a new style instrument and visa-versa.

**( Original Styles )**

**15744 - Composite**

**15849 - Stainless Steel**

- Newer models HAVE the new style keypad with an ON/OFF switch, and are ordered WITH or WITHOUT battery option. All contain the "bAtt" menu in their software.

Parts from an original may NOT be used in a new style instrument and visa-versa.

**( Newer Styles)**

**22258** - AC Only Stainless Steel

**21877** - AC Only Composite

**21879** - AC/Battery Composite

**22260** - AC/Battery Stainless Steel

The 2300 Series is available in an ABS hostile environment version and in a hostile environment SS enclosure. The enclosure(s) come with a mounting bracket suitable for desk or wall mount.

Options are Time Clock and 4-20mA output accessories.

C. Intended Applications:

Include, but are not limited to:

- Tank weighing assemblies
- Floor scales
- Bench scales
- Hopper scales
- Truck scales



## Section 3: Setup

### A. Unpacking:

Be certain the instrument is undamaged and the packing list is correct.

### B. Installing:

Setup is accomplished by locating and securing the instrument within a suitable area, wiring to the load cell(s) or junction box, programming to meet specific needs, calibration, then adding peripheral equipment as required. Place the instrument so that the platform can be viewed while operating, out of direct sun, and close to a power outlet if AC power is to be used. Configuration, calibration, accessory installation and peripheral device setup must be performed by an authorized installing technician. The instrument stand is attached via the two (2) screw knobs and used as a desk mount, or a wall mount using the pre-drilled holes in the base of the stand.



**Note:** *When adjusting screw knobs, hand tighten only, do NOT overtighten.*

1. AC Power can be set for 110/120VAC OR 220/240VAC via jumpers @ JP1 on Power PCB# 15759 or 21514, confirm setting.

For 220/240VAC = Jumper only center position "B"

For 110/120VAC = Jumper both end positions "A" and "C"

### 2. Models with battery option:

**a. Stainless Steel:** Open the battery holder's cover by loosening the four thumbscrews and insert 6 NEW "D" (alkaline) cells into the holder observing polarity. Ensure all batteries are inserted correctly, then secure screws before powering up.

**b. Composite:** Remove the battery holder cover and insert 6 NEW "D" (alkaline) cells into the holder observing polarity. Ensure all batteries are inserted correctly, then secure cover before powering up.



### C. Power On:

To turn power ON, firmly press the ON/OFF switch on the front panel. On original models, without the ON/OFF switch, simply plug the power cord in to power up.


A 'Power-up' display will sequence is as follows:

<b>LL.LLLL</b>	(digit test)
<b>777.777</b>	(digit test)
<b>- - - -. - -</b>	(digit test)
<b>init.</b>	(initialization)
<b>P21579</b>	(or current Prom # )
<b>Rev 2</b>	(or current Rev #)
<b>X.X U</b>	(battery voltage)
<b>XX.XCs</b>	(temperature)
<b>XX.XCn</b>	(temperature)
<b>Adinit</b>	(A-D Initialization)
<b>Stby 25-1</b>	(Countdown for A-D Initialization)
<b>XXX.X</b>	(weight display)















# Section 4: Programming


## A. Keyboard Layout:

Description of front panel keys and their function(s):



**Note:** The original model's keypad does NOT have an ON/OFF switch key.

-  Used the enter PROGRAM mode
-  Used to view choices in PROGRAM mode
-  Used to set ID or Identification number
-  Changes from GROSS to NET modes/ exits from Program mode.
-  Selects weighing Units
-  Captures weight on platform as TARE, sets display to 00
-  Resets display to 00
-  Reads current stored TARE weight
-  Sends data to printer device(s)
-  Transacts "keyed" data into memory
-  Number 0 to 9 for ID or Tare entries & used in programming
-  & used in programming
-  Decimal for data entry in decimals
-  Press FIRMLY to turn power ON, then OFF




## B. Getting Started with Menus and Programming:

1. The **Main Menu** is accessed from the weigh screen by pressing PGR. The Main Menu's layout is shown here:


'Pgr' = Program

'S' = Scroll



- Each Main menu is accessed by pressing ENTER with the Main menu legend displayed
- Each Main menu contains sub-menus
- Each sub-menu contains data
- Data can be viewed by pressing the SCROLL key, and 'accepted' by pressing ENTER
- Pressing the SCROLL key repeatedly will exit to a menu
- Pressing the GROSS/NET key repeatedly will exit to the weigh screen
- Menus can be accessed in any order for adjustments or calibration


<u>Menu</u>	<u>Description</u>
<b>Info</b>	NO password needed, set Time & Date, view data, print config reports
<b>io</b>	"U" code required, set up all ports for printers, and other devices and outputs
<b>BAtt</b>	NO password needed, view battery voltage, set sleep time and display brightness (Original instruments did NOT have the bAtt menu)
<b>CAnnEd</b>	"S" code required, clears memory and sets a default program
<b>ConFiG</b>	"S" code required, set all weighing parameters here
<b>CAL</b>	"S" code required, calibrate zero and span
<b>CALno0</b>	"S" code required, re-calibrate without emptying or zeroing scale



### C. info Menu:

The info menu may be accessed without a code. This menu may be looked at by Weights and Measures to check the "S Audt", "U Audt", or "C Audt" for entries after a seal has been attached. This menu contains other good information such as CoUntS for checking live counts, dEg C for checking the ambient temperature of the instrument location, and CPg or the counts per division. IF installed, time & date settings are accessed here.

- Press 'Pgr' to enter the program mode



- Press ENTER at the inFo menu

<u>Prompts are:</u>	<u>Results are:</u>
<b>CoUntS</b>	XXXXXX
<b>dEg C</b>	XX.X ° C
<b>U AUdt</b>	User Audit
<b>S AUdt</b>	Service Audit
<b>C AUdt</b>	Calibration Audit
<b>Cpg</b>	Counts/Grad
<b>dAtE</b>	Date setting shows ONLY IF Time/Date Accessory is installed
<b>hoUr</b>	Time setting shows ONLY IF Time/Date Accessory is installed
<b>rEPort</b>	Report




- With any prompt showing, press ENTER to 'view' the information at that prompt.
- Press ENTER again and the display will advance to the io menu.
- Use the SCROLL key to exit programming to the weigh mode.

### **1. Setting Time and Date:**

The time and Date prompts will show ONLY if the time clock accessory 15819 is installed.

- Press 'Pgr' to enter the program mode
- inFo will be shown, press ENTER to go into the inFo menu
- Use 'Scroll' to go to the "dAtE" menu and press ENTER
- The existing date, "XXXXXX" will be displayed
- Use the keypad to enter the correct date in mmddyy format
- Press ENTER, the display will show "hoUr"
- Press ENTER, the display will show the existing time "XX.XX"
- Use the keypad to enter the correct time "XX.XX"
- Press AUTOTARE for "AM" or PRINT for "PM", an "A" or "P" will be added
- With the proper Time shown, press ENTER
- The display will show "rePort", press SCROLL repeatedly to exit to the weigh mode
- DONE

**D. bAtt Menu:** This menu is used for checking battery voltage, setting 'sleep' time, and display brightness. No passwords are required to access this menu.



**To access the BAtt menu:**

- Press 'Pgr' to enter the program mode
- Use 'Scroll' to go to the BAtt menu
- Press ENTER

**Prompts are:**

**XX.X U**

**\*SLEEP**

**SL 0**

**SLEEP**

**bright**

**StorE**

**StorEd/CAnnEd** Press GROSS/NET

**Choices are:**

The voltage reading of the installed batteries (U="V"olts)

**NOTE:** If AC power is used, the indication will NOT be accurate!

Press ENTER or SCROLL to advance

The number of INACTIVE MINUTES before \*'sleep' occurs

Press ENTER or SCROLL to advance

Enter 0=No sleep, 1-99 are active valid entries (use SCROLL)

Press SCROLL to advance

Hi, Lo (Use Lo to extend battery life by about 20%)

Press SCROLL



**Note:** If either SLEEP or BRIGHT are accessed, the SCROLL key will advance to STORE. If neither are accessed, then SCROLL will 'loop' SLEEP-to-BRIGHT until an entry is made, or, the Gross/Net key is pressed repeatedly to exit programming and return to the weigh mode.

\* **The 'sleep' option:** If the scale is idle at "0" (zero) for the amount of programmed 'sleep' time, the display will start to scroll dashes (- - - - -) from right to left and momentarily flash "ASLEEP". It will stay this way for about 5 minutes if the scale is undisturbed, then turn OFF. If the scale is used in that 5 minute period, it will resume weighing, and reset the 'sleep' timer. The ON/OFF switch must be pressed to repower the unit if it turns itself OFF.

## Section 5: Operation

### A. Keyboard features:

Include eight (8) LED indicators that "light" when that function or parameter is selected.

<b>ID</b>	Indicates the instrument is in the ID entry mode.
<b>PROGRAM</b>	Indicates the instrument is in the program mode
<b>lb</b>	Indicates pounds (lb) is selected as the weighing unit
<b>kg</b>	Indicates kilograms (kg) is selected as the weighing unit
<b>oz</b>	Indicates ounces (oz) is selected as the weighing unit
<b>g</b>	Indicates grams (g) is selected as the weighing unit
<b>*lb &amp; oz</b>	Indicates pound-ounces (lb-oz) is selected as the weighing unit
<b>TARE</b>	Indicates the inst. is in the TARE mode, displays TARE weight
<b>NET</b>	Indicates the inst. is in the NET mode, displays NET weight

\* The lb-oz unit is NOT LEGAL for TRADE, do NOT use in commercial applications.



**Notes:** If neither TARE or NET are selected, the instrument is in GROSS mode.

### B. Other Key Functions:

#### 1. Using ID

Press ID, then press numeric keys 0-9 (up to six [6] digits) for unique customer or container number.

Example:

Press ID, 55147, then press ENTER, 55147 is temporarily stored as ID.

ID can then be printed on a ticket to identify a weighment.

ID is not saved through power reset.

#### 2. Using TARE

Enter numeric value in proper units, then press ENTER. Value becomes a stored TARE weight. Enter 0, then ENTER to set a "zero" tare. Press TARE to view temporary TARE weight. Tare is not saved through power reset.



### **3. Using UNITS**

IF 2 or more UNITS are set up in programming, then pressing the UNITS key will toggle through all choices. Selecting units will show another division size, and possibly different decimal places. Units reset to primary unit on power reset.

## **C. Weighing Operation**

### **1. Gross Weighing**

- a. Use ZERO key to set scale to 0.0
- b. Place container/vehicle on scale
- c. If ID is desired, Press ID, enter numeric ID, press ENTER
- d. Record/Read GROSS weight

### **2. Net Weighing**

- a. Use ZERO key to set scale to 0.0
- b. Place container/vehicle on scale (Tare weight)
- c. Press AUTOTARE or enter TARE weight via keypad
- d. Place material in container/vehicle (net weight)
- e. If ID is desired, Press ID, enter numeric ID, press ENTER
- f. Record/Read NET weight

### **3. Gross/Tare/Net Weighing**

- a. Use ZERO key to set scale to 0.0
- b. Place container/vehicle on scale (Tare weight)
- c. Press AUTOTARE or enter TARE weight via keypad
- d. Place material in container/vehicle (Net weight)
- e. Press Gross/Net
- f. If ID is desired, Press ID, enter numeric ID, press ENTER
- g. Record/Read Gross/Tare/Net Weight

## Section 6: Troubleshooting

Symptom	Cause	Remedy
ON/OFF sw will NOT turn ON (AC Power)	Sw not pressed firmly No power at outlet Faulty Instrument	Press the ON/OFF switch FIRMLY and SLOWLY to turn ON Check AC outlet Call for Service
ON/OFF sw will NOT turn OFF	Display must be in weight display mode	Press SCROLL to return the display to the weighing mode Press the ON/OFF switch FIRMLY to turn OFF
Blank with AC power	No Power Faulty Instrument	Check power, check outlet, check plug, check cord, replace power PCB, replace main PCB
no rEF	No Load Cell Reference	Connect simulator to test, attach load cell, replace load cell cable, replace load cell
InPErr	Input Error	Call for Service
Lo CPd	Low Counts per Division	Call for Service
LoSPAN	Low Span Weight(s) Used	Call for Service
LoLoAd	Low Load, below ZERO reference	Remove platform bind, Call for Service
HiLoAd	High Load, above scale capacity	Remove Heavy Load, Call for Service
ESdrSt	Electro Static Discharge Reset	Check grounds, check for 3 prong plug, reinitialize power, Call for Service
gt6chr	More than 6 Characters	Call for Service
ON/OFF sw Inop (Batteries)	Sw not pressed firmly Batteries dead Faulty Instrument	Press the ON/OFF switch FIRMLY and SLOWLY Replace ALL 6 batteries with NEW alkaline "D"cells Call for Service
Blank DC power	Batteries BELOW 6.4 VDC	Replace ALL 6 batteries with NEW alkaline "D"cells
LoBAtt	Batteries at about 6.4 VDC	Replace ALL 6 batteries with NEW alkaline "D"cells
LoBAtt 'Flashing'	Batteries BELOW 6.4 VDC	Replace ALL 6 batteries with NEW alkaline "D"cells
Was ON now Blank	Sleep 'timed out'	Press the ON/OFF switch to repower unit
SLEEP/ BRIGHT 'loop'	SCROLL key	Access either SLEEP or BRIGHT via the ENTER key, the SCROLL key will now advance.(If neither are accessed, the SCROLL key will 'loop' these parameters).

# Appendix I: PTR-3950 Ticket Printer Information

**PTR-3950 Switch Settings:**

	SW1	SW2
	12345678	12345678
	01100011	10010010

**2400, None, 8 Bits, Busy=0      Use Cable 15598 ( Acc 1296 )**

**Printout of REPORT  
in INFO menu**

Port 2:  
2400  
none  
8  
CRLF  
3950

Port 1:  
2400  
none  
8  
Frbnks

EXSW2 = >0<  
EXSW1 = PRINT

1ND2300:  
d/PU      1 LB  
UNITS   LB KG OZ GM LB-OZ  
kb tare  
auto tare  
AZT Id  
0 RANGE 100%  
MOT 1d  
Filter MEDIUM  
Security: Software lock disabled  
Hardware lock disabled

Analog Loop:  
Lo W = 00  
Hi W = 18500  
Lo I = 0  
SPAN = 102  
gross

Platform:  
PU Cap = 1000  
PU Cpd = 637.508000  
0 ref = 348458

Battery:  
Voltage = 27.3  
Sleep Time = 0  
Intensity = Lo

**Printout of U Audit  
in INFO menu**

User Audit    57  
Audit Date 092898

**Printout of Ticket**

1670 lb GROSS

1000 lb    NET

670 lb    TARE

125 ID



# Appendix III: 50-3921 Form Printer Information

## 50-3921 Form Printer Switch Settings:

SW1(super spd ser bd)	SW2 (super spd ser bd)	DipSW (Main PC)
12345678	12345678	12345678
11111111	01100110	00001010

**9600, None, 8 Bits, Busy=0**

**Use cable 15599 ( Acc 1297 )**

### Printout of REPORT in INFO menu

Port 2:  
9600  
none  
8  
CRLF  
3921

Port 1:  
2400  
none  
8  
Frbnks

EXSW2 = >0<  
EXSW1 = PRINT

1ND2300:  
d/PU .01 OZ  
UNITS LB KG OZ GM LB-OZ  
kb tare  
auto tare  
AZT Id  
0 RANGE 100%  
MOT 1d  
Filter MEDIUM  
Security: Software lock disabled  
Hardware lock disabled

Analog Loop:  
Lo W = 00  
Hi W = 18500  
Lo I = 0  
SPAN = 102  
gross

Platform:  
PU Cap = 1000  
PU Cpd = 637.508000  
0 ref = 348458

Battery:  
Voltage = 27.3  
Sleep Time = 0  
Intensity = Lo

### Printout of Uaudt in INFO menu

User Audit 16  
Audit Date 092898

### Printout of Ticket

30.00 oz GROSS  
12.50 oz NET  
17.50 oz TARE

4077 ID

# Appendix IV: 610 Ticket Printer Information

## 610 Switch Settings:

## Switch 1

12345678

01001011

## 1200, Odd, 7 Bits, Busy=1

## Use cable 15598 (Acc 1296 )

### Printout of REPORT in INFO menu

Port 2:

9600

none

8

CRLF

3921

Port 1:

2400

none

8

Frbnks

EXSW2 = >0<

EXSW1 = PRINT

1ND2300:

d/PU .01 OZ

UNITS LB KG OZ GM LB-OZ

kb tare

auto tare

AZT Id

0 RANGE 100%

MOT 1d

Filter MEDIUM

Security: Software lock disabled

Hardware lock disabled

Analog Loop:

Lo W = 00

Hi W = 18500

Lo I = 0

SPAN = 102

gross

Platform:

PU Cap = 1000

PU Cpd = 637.508000

0 ref = 348458

Battery:

Voltage = 27.3

Sleep Time = 0

Intensity = Lo

### Printout of Uaudt in INFO menu

User Audit 11

Audit Date 101098

### Printout of Ticket

30.00 oz GROSS

12.50 oz NET

17.50 oz TARE

555555 ID

# Appendix V: 3550 Tape Printer Information

**3550 Switch Settings:** SW1 = 0111010100  
SW2 = 11111010

**3715 Setting, Busy 0, 4800 baud, 8 bits, no parity**  
**Use Cable 15597 (ACC 1295)**

**Printout of REPORT**  
**in INFO menu**

Port 2:  
9600  
none  
8  
CRLF  
3921

Port 1:  
2400  
none  
8  
Frbnks

EXSW2 = >0<  
EXSW1 = PRINT

1ND2300:  
d/PU .01 OZ  
UNITS LB KG OZ GM LB-OZ  
kb tare  
auto tare  
AZT Id  
0 RANGE 100%  
MOT 1d  
Filter MEDIUM  
Security: Software lock disabled  
Hardware lock disabled

Analog Loop:  
Lo W = 00  
Hi W = 18500  
Lo I = 0  
SPAN = 102  
gross

Platform:  
PU Cap = 1000  
PU Cpd = 637.508000  
0 ref = 348458

Battery:  
Voltage = 27.3  
Sleep Time = 0  
Intensity = Lo

**Printout of Uaudt**  
**in INFO menu**

User Audit 11  
Audit Date 101098

**Printout of Ticket**

30.00 oz GROSS  
12.50 oz NET  
17.50 oz TARE

555555 ID

# Appendix VI: 3715 Tape Printer

<b>50-3715 Switch Settings:</b>	<u>Switch 1</u>	<u>Switch 2</u>
	12345678	12345678
	00000100	01001010

**2400, None, 8 Bits, Busy =1      Use cable 15597 (Acc 1295)**

**Printout of REPORT  
in INFO menu**

Port 2:  
9600  
none  
8  
CRLF  
3921

Port 1:  
2400  
none  
8  
Frbnks

EXSW2 = >0<  
EXSW1 = PRINT

1ND2300:  
d/PU      .01 OZ  
UNITS   LB KG OZ GM LB-OZ  
kb tare  
auto tare  
AZT Id  
0 RANGE 100%  
MOT 1d  
Filter MEDIUM  
Security: Software lock disabled  
Hardware lock disabled

Analog Loop:  
Lo W = 00  
Hi W = 18500  
Lo I = 0  
SPAN = 102  
gross

Platform:  
PU Cap = 1000  
PU Cpd = 637.508000  
0 ref = 348458

Battery:  
Voltage = 27.3  
Sleep Time = 0  
Intensity = Lo

**Printout of Uaudt  
in INFO menu**

User Audit      11  
Audit Date 101098

**Printout of Ticket**

30.00 oz GROSS  
12.50 oz NET  
17.50 oz TARE

555555 ID





# Appendix VIII: 295 Ticket Printer

**295 Switch Settings:**     Switch 1  
                                  All Off

**9600, None, 8bits, Busy = 0     Use cable 15599 (Acc 1297)**

<u>Printout of REPORT</u> <u>in INFO menu</u>	<u>295</u>	<u>TB2</u> <u>2300</u>
Port 2:	2	1
9600	3	2
none	7	4
8		
CRLF		
TM-U295		
Port 1:		
2400		
none		
8		
none		
EXSW2 = none		
EXSW1 = none		
1ND2300:		
d/PU           0.1 LB		
UNITS   LB KG OZ GM		
kb tare		
auto tare		
AZT 3d		
0 RANGE 100%		
MOT 3d		
Filter CENTER		
Security: Software lock disabled		
Hardware lock disabled		
Analog Loop:		
Lo W = 6.6		
Hi W = 800.0		
Lo I = 0		
SPAN = 103.2		
gross		
Platform:		
PU Cap = 1000.0		
PU Cpd = 26.217100		
0 ref = 524250		
Battery:		
Voltage = 16.1		
Sleep Time = 0		
Intensity= Hi		

# Appendix IX: Interface Cables/Pin-Outs

## Port 1 RS232 (continuous)

From TB4 in the indicator	3715 25Pin	3950 25Pin	3921 25Pin	3960 25Pin	Computer 25 Pin	Computer 9 Pin	RMT140XA (using RS232)
Pin 1 TX RS232					<b>3</b>	<b>2</b>	<b>3</b>
Pin 2 GND					<b>7</b>	<b>5</b>	<b>2</b>
Pin 3 +5V							
Pin 4 +20mA							
Pin 5 -20mA							

## Port 1 20mA

From TB4 in the indicator	RMT 140XA/150X
Pin 4 +20mA	<b>1</b>
Pin 5 -20mA	<b>5</b>
	<b>2</b> } jumper
	<b>6</b> }

## Port 2 RS232

From TB2 in the indicator	3715 25Pin	3550 25 Pin	3950 25 Pin	3921 25 Pin	3960 25 Pin	Comp 25 Pin	Comp 9 Pin	TMU 590	TMU 295
Pin 1 RX				<b>2</b>	<b>2</b>	<b>2</b>	<b>3</b>	-	<b>2</b>
Pin 2 TX	<b>3</b>	<b>3</b>	<b>3</b>	<b>3</b>	<b>3</b>	<b>3</b>	<b>2</b>	<b>3</b>	<b>3</b>
Pin 3 CTS	<b>20</b>	<b>20</b>	<b>4</b>					<b>4</b>	-
Pin 4 GND	<b>7</b>	<b>7</b>	<b>7</b>	<b>7</b>	<b>7</b>	<b>7</b>	<b>5</b>	<b>7</b>	<b>7</b>
Pin 5 RTS									
Cable Acc	15597	15597	15598	15598	15599	15599			

## Port 2 RS485

From TB3 in the indicator	3715 25 Pin	3950 25 Pin	3921 25 Pin	3960 25 Pin	Comp 25 Pin	Comp 9 Pin	RMT 140XA
Pin 1 485+					RX+	RX+	-
Pin 2 485-					RX-	RX-	-
Pin 3 GND							-
Pin 4							-
Pin 5							-

# Appendix X: Port 1 Data Stream

## Port 1 Continuous Output Data Stream:

Selected Format	Char	Assignment
Fairbanks Std	1st	Stx
	2nd	'4'
	3rd	'0' gross lbs or ounces '1' net lbs or ounces '3' gross kgs or grams '4' net kgs or grams
	4th thru signed weight string e.g. 9th or 10th	'- 12.33' or ' 20' or '- 1'
	10th	Etx
	Weightronix	1st
2nd		'N' " " 'G' " "
3rd thru signed weight string e.g. 8th or 9th		'-12.33' or ' 20' or '- 1'
9th, 10th & 11th OR 10th, 11th, & 12th		'lb' or 'kg' or 'g' or 'oz' or 'lb-oz'
12th & 13th OR 13th & 14th		Cr and Lf
Consolidated Controls	1st	Stx
	2nd thru signed weight string e.g. 7th or 8th	'-12.33' or ' 20' or '- 1'
	9th or 10th 10th or 11th	'L' or 'K' or 'G' or 'O' 'O' or 'I' indicator Error 'M' Motion ' ' No Motion
	12th or 13th	Cr
dPlus	1st	Sx
	2nd	STATUS WORD A <b>Bit            Decimal point or Dummy Zero</b> x00   x0   x   x.x   x.xx   x.xxx   x.xxxx   x.xxxxx 0   1   1   0   0   1   0   1   0 1   1   0   0   1   1   0   0   1 2   1   0   0   0   0   1   1   1

dPlus

3rd

4th

5th thru 10th unsigned  
6 character gross weight  
string without decimal e.g.

11th thru 16th 6 character  
tare weight string  
without decimals e.g.

17th

Bit	Increment Size		
	Count by 1	Count by 2	Count by 5
3	1	0	1
4	0	1	1
5	Always Logic 1		
6	Always Logic 1		
7	Parity Bit		

**STATUS WORD B**

Bit		
0	Gross = 0	Net = 1
1	Positive = 0	Negative = 1
2	In Range = 0	Overcapacity = 1
3	No Motion = 0	Motion = 1
4	Avoidupois = 0	Metric = 1
5	Always Logic 1	
6	Always Logic 0	
7	parity bit	

**STATUS WORD C**

Bit	
0	Always Logic 0
1	Always Logic 0
2	Always Logic 0
3	Normal = 0 Print Operated Switch = 1
4	Always Logic 0
5	Always Logic 1
6	Normal = 0 Keyboard Tare = 1
7	parity bit

'-12.33' SENT AS ' 1233' or  
' 20' or  
'- 1' SENT AS ' 1'

' 12.33' SENT AS ' 1233' or  
' 20' or  
'- 1' SENT AS ' 1'

Cr

## Appendix XI: 4-20mA Option

The 4-20mA analog output can be used to drive chart recorders, logic controllers or computers. The indicator is passive as it relates to the 4-20mA signal. The power for the signal **MUST** come from the customer's equipment. That equipment **MUST** be capable of supplying a minimum of 7 to a maximum of 40 volts of power to that circuit. Common voltages supplied are 12-24 vdc.

### Specifications:

- 16 bit resolution
- +/- .01 integral linearity
- Current loop voltage compliance: 7 vdc minimum to 40 vdc maximum (typical voltage 24 vdc)
- Full scale settling time: 8 msecs
- Output impedance: 25 meg
- Alarm current: 3.5 to 24 mA (underload/overload conditions)
- Offset @ 25 degrees C; +/- .1% of full scale
- Offset drift: +/- 25 ppm of full scale per degree C
- Total output error: (20mA) @ 25 degrees C: +/- .2% of full scale max
- Total output drift: +/- 50 ppm of full scale per degree C max

For supplying signal levels other than 4 to 20mA, use the following formula example:



$$\begin{aligned}\text{Supply voltage} &= \mathbf{12V} \\ 4\text{mA} \times 500 \text{ ohms} &= \mathbf{2V} \\ 20\text{mA} \times 500 \text{ ohms} &= \mathbf{10V}\end{aligned}$$

The above example would provide a 2-10V analog, adjustable signal. The sense resistor or the power supply may be changed to accommodate different levels.

Do NOT exceed the power supplied by the customer's equipment, i.e., 12V. Leave at least a 10% margin so that the power supplied is at least 10% greater than the signal being sent at maximum output. Use the following illustrations for wiring.

**Warning:** *The (-) terminal of the customer's power supply must NOT be connected to or shorted to instrument case ground or catastrophic failure will occur.*

# Appendix XII: 4-20mA Option *Continued*



50523-16

## Appendix XIII: ASCII Chart

Decimal Code #	Control Char	Decimal Code #	Control Char	Decimal Code #	Control Char	Decimal Code #	Control Char
0	NUL	33	!	66	B	99	c
1	SOH	34	"	67	C	100	d
2	STX	35	#	68	D	101	e
3	ETX	36	\$	69	E	102	f
4	EOT	37	%	70	F	103	g
5	ENQ	38	&	71	G	104	h
6	ACK	39	'	72	H	105	i
7	BEL	40	(	73	I	106	j
8	BS	41	)	74	J	107	k
9	HT	42	*	75	K	108	l
10	LF	43	+	76	L	109	m
11	VT	44	,	77	M	110	n
12	FF	45	-	78	N	111	o
13	CR	46	.	79	O	112	p
14	S0	47	/	80	P	113	q
15	S1	48	0	81	Q	114	r
16	DLE	49	1	82	R	115	s
17	DC1	50	2	83	S	116	t
18	DC2	51	3	84	T	117	u
19	DC3	52	4	85	U	118	v
20	DC4	53	5	86	V	119	w
21	NAK	54	6	87	W	120	x
22	SYN	55	7	88	X	121	y
23	ETB	56	8	89	Y	122	z
24	CAN	57	9	90	Z	123	{
25	EM	58	:	91	[	124	
26	SUB	59	;	92	\	125	}
27	ESC	60	<	93	]	126	~
28	FS	61	=	94	^	127	Delete
29	GS	62	>	95	-		
30	RS	63	?	96	`		
31	US	64	@	97	a		
32	Space	65	A	98	b		



**NOTE:** Refer to your printer or computer's User Manual for special control codes that your printer or computer may require for proper operation.