



| ITEM | QTY | PART         | DESCRIPTION                          |
|------|-----|--------------|--------------------------------------|
| 1    | 1   | 96MK1939-20  | REPAIR KIT (Includes Items Marked *) |
| 2    | 1   | 96MK1728-4   | PUMP PISTON                          |
| 3    | 1   | 96MK1728-2   | PUMP BARREL                          |
| 4 *  | 1   | 96MK1728-7   | PUMP PISTON WIPER                    |
| 6 *  | 1   | 96MK1728-5&6 | PUMP PACKING AND BACK UP             |
| 7    | 1   | 1035-P       | COLLAR, 1/2", RELEASE VALVE          |
| 8    | 1   | 1040-P       | 1/4 - 20 X 2-1/2 SHCS STL            |
| 9 *  | 1   | 96P1-20      | PUMP BARREL "O" RING                 |
| 10   | 1   | 96CP13-10RP  | PISTON PIN (INCLUDES RINGS)          |
| 11   | 2   | 96CP13-10RP  | LINK PIN (INCLUDES RINGS)            |
| 12 * | 1   | 96P1-12RP    | PUMP VALVE (COMPLETE)                |
| 13   | 1   | 96CP13-13RP  | OVERLOAD VALVE (COMPLETE)            |
| 14   | 1   | 96MK1939-3RP | RELEASE VALVE (COMPLETE)             |
| 15   | 1   | 96CP13-23    | LEVER HANDLE                         |
| 16   | 1   | 96P1-16      | BREATHER SCREW                       |
| 17   | 1   | 96CP13-9     | PUMP SOCKET                          |
| 18   | 1   | 96CP13-12    | PUMP LINK                            |
| 19   | 1   | 96MK1939-P   | PUMP, HYD, HAND, STAR                |

\* Included in item 1, Repair Kit, 96MK1939-20