

Auxiliary Valve Kit 1111-P for 400 Series Power Lift Units

- Allows metering the lowering of the lift cylinder
- Can be closed for positive hold

Installation Instructions:

1. Fully Lower Overhead
2. Remove hose from pump
3. Install flow control valve with arrow in the direction shown
4. Connect hose to flow control valve using the hose fitting
5. When overhead is at desired position, close flow control valve
6. To lower overhead, open flow control valve and operate hydraulic valve

1111-P Auxiliary Valve Kit

(PARTS CALLED OUT BELOW)

- Allows metering the lowering of the lift cylinder
- Can be closed for positive hold

