


CONTENTS

	Page
Installation Instructions	1 - 2
Dimensions	2
Operating Instructions	2 - 3
Parts Diagram	. 4

INSTALLATION INSTRUCTIONS

- Position Rim Clamp Assembly on **INSIDE** of drum holder bracket (item 1) with holes aligned
- Bolt in place with
 bolts (item 2) and
 washers (item 3)
 using 9/16" wrench



WARNING:

This product can expose you to chemicals including barium sulfate, cobalt, titanium dioxide, and 2-methylimidazole, which are known to the State of California to cause cancer, and bisphenol-A, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov

morsedrum.com

service@morsedrum.com

(315) 437-8475

103 Kuhn Rd. Syracuse, NY, 13208 U.S.A.



Form PL4560BM-P (0322-____)

(Updated 1 Mar, 2022)

1

Kit # 4560BM-P Kit: Adjustable Rim Clamp

Operator's Manual

for Morse Adjustable Rim Clamp Kit


Kit # 4560BM-P Serial number 0322 to ____ (MMYY)



Kit # 4560BM-P Kit: Adjustable Rim Clamp

Operator's Manual for Morse Rim Clamp Assembly Kit # 4560BM-P Serial Number 0322 to _____ (MMYY)

DIMENSIONS




BEFORE OPERATING RIM CLAMP

Set Correct Rim Clamp Position for 55-Gallon OR for 30-Gallon Drum (210 Liter OR 114 Liter Drum)

Insert pin through correct holes to set Top Rim Clamp to position for ONE of the following drum sizes:

- 1. 55-gallon (210 liter) size drum
- 2. 30-gallon (114 liter) size drum



Form PL4560BM-P (0322-___)



Kit # 4560BM-P Kit: Adjustable Rim Clamp

Operator's Manual for Morse Rim Clamp Assembly Kit # 4560BM-P Serial Number 0322 to _____ (MMYY)

OPERATING INSTRUCTIONS

Steps to Secure Drum

STEP 1.

Tighten cinch chain or web strap around drum just enough to hold drum with bottom jaw of Top Rim Clamp positioned under top rim of drum.

Swing bottom jaw into position against drum sidewall to engage directly beneath drum top rim.

STEP 2.

Swing top hook over top rim of drum and turn hand wheel clockwise until SECURELY clamped over drum top rim.


STEP 3.

Securely tighten cinch chain or web strap around drum.

STEP 4.

IMPORTANT: Lift Drum <u>SLIGHTLY</u>... Then ensure:

- 1. Bottom jaw is engaged under drum top rim
- 2. TIGHTEN Top jaw to ensure it grips drum top rim



Steps to Release Drum


- 1. Lower drum to floor in upright position
- 2. Release cinch chain or web strap from around drum
- 3. Open Top Rim Clamp by turning knob counter clockwise
- 4. Disengage hook from drum top rim

morsedrum.com Copyright 2022 - Morse Mfg. Co., Inc.



Kit # 4560BM-P Kit: Adjustable Rim Clamp

Operator's Manual for Morse Rim Clamp Assembly Kit # 4560BM-P Serial Number 0322 to ____ (MMYY)



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	6490-P	KNOB 2-1/2" DIA 1/2-13 TAP	1
2	6627-P	SPACER, NYLON, 1/2"OD .505"ID	1
3	6487SS-P	HOOK WELD, 4560-P, ADJ	1
4	6590-P	SPRING, KNOB, 4560-P	1
5	6484T-P	ROD END BOLT, 1/2-13 X 6"	1
6	3461-P	E CLIP, 1/2", 82	2
7	151-P	STOP SPACER, 90	2
8	6504-P	PIN, GROOVE, 1/2 X 2.080"	1
9	6480BWM-P	LOWER JAW WELD, 4560-P	1
10	6548-P	PIN, QUICK, BENT, 1/2 X 2-1/2	1
11	6489WM-P	SUPPORT TUBE WELD SR 4560BM-P	1
12	1474-P	WASHER, 3/8 SPLIT LOCK	2
13	1572-P	HHCS, 3/8-16 X 1 GR2 ZINC	2

4