

## **Morse 1-5-1 Idler Attachment to roll a 1 to 5 gallon can on Morse Drum Roller**

### **Assembly Instructions**

1. Fasten base onto the rotator channel as shown in diagram. Use the two bolts and whiz-lock nuts provided.
2. With the roller tube, collars, roller axle, tube bearing, and roller holder assembled as shown, slide both roller holders directly inside each roller base tube. Tighten down both collars on roller holders.
3. Adjust large collars on the roller tube far enough apart so that the can rolls between them.
4. Adjust the drive wheels on the rotator to roll the can.